



F13-01



F13-02



F13-03



F13-04



F13-05



F13-06



F13-07



F13-08



F13-09



F13-10



F13-11



F13-12

各种吸塑面罩 plastic cover of balancer



F13-13



F13-14



F13-15



F13-16



F14-01



F14-02



F14-03



F14-04



F14-05



F14-06



F14-07



F14-08



F14-09



F14-10



F14-11



F14-12



F14-13



F14-14



F14-15



F14-16

涡轮箱总成 gear box assembly



F1-01



F1-02

涡轮 gear



F1-03



F1-04



F1-05

皮带轮 belt pulley



F1-06



F1-07



F1-08



F1-09

技术参数 Technical Data

模数	Modulus	2 m
齿数	Tooth number	100 Z
数比	The number compares	1/100
转速	Speed	6.5转/分 r/min
重量	Weight	15kg
噪声指数	Noise level	<60db

质量特征 Mass characteristic

壳体	Case	铝压铸
涡轮	Gear	HT20-40
蜗杆	Worn	45#积压型 齿面粗糙度0.8
主轴	Principal axis	45#调质 HB217-255
轴承	Bearing	6205 6010 6508
润滑油	Lubricant	重负荷齿轮油 ZC-5

蜗杆 worm



F2-01

气缸杆 cylinder stem



F2-02

小气缸端盖 cover of small cylinder



F2-03



F2-04

大气缸 cylinder of tyre changer



F2-05



F2-06



F2-07

小气缸 small cylinder



F2-08



F2-09



F2-10

工作台总成 turntable assembly




F2-11



F2-12



F2-13



F2-14

脚踏总成 pedal switch assembly



F3-01



F3-02



F3-03

各种脚踏控制板 all kinds of pedal control



F3-04



F3-05



F3-06



F3-07



F3-08



F3-09



F3-10



F3-11

大铲护套 Protection of beadplate



F3-12



F3-13

卡爪护套 clamp protector



F3-14



F3-15



F3-16


卡爪 clamp



F3-17



F3-18



F3-19



F3-20

小船 boat

大胶板 rubber plate



F3-21



F3-22



F3-23

扒胎机皮带 belt of tyre changer



F3-24

回转连接器 rotary connector



F4-01



F4-02



F4-03



F4-04



F4-05

两位五通换气阀 switch valve with two-position and five-pass



F4-06



F4-07



F4-08



F4-09

阀杆 valve stem



F4-10

隔套、胶圈 spacer & rubber spron



F4-11



F4-12

塑料工具头 plastic demounting heads



F4-13



F4-14



F4-15



F4-16

铸钢工具头 cast steel demounting heads



F4-17



F4-18



F4-19



F4-20



F4-21



F4-22

自动翻转工具头 automatic flip demounting heads



F4-23



F4-24



F4-25

翻转工具头 flip demounting heads




F4-26



F4-27

大气缸密封圈 seals of big cylinder



大气缸活塞(铝制) piston of big cylinder



小气缸密封圈、活塞 seals & piston of small cylinder



大气缸活塞(橡胶) piston of big cylinder



拉杆、滑道 tension rod & slide



各种管接头 all kinds of joints



快排阀 quick exhaust valve



钢圈保护套 protection cover of steel ring



油水分离器 air regulator



工具头护垫 protection cover of demounting heads



六方杆压盖 cover of hexagonal stem



梅花把手 star handle




拉簧 pullback spring



扭簧 torsional spring



大气缸弹簧 cylinder spring



弹片 flexure strip



六方杆弹簧 six-party stem spring



工具头滚轮 roll and pin of tool heads



倒顺开关 reversible switch



倒顺开关支架 reversible switch bracket



倒顺开关护罩 protector cover of reversible switch switch



辅助臂各种配件 plastic spare parts of helper



F7-01 F7-02 F7-03 F7-04 F7-05



F7-06 F7-07 F7-08 F7-09 F7-10



F7-11 F7-12 F7-13 F7-14 F7-15



F7-16 F7-17 F7-18 F7-19 F7-20

辅助臂压胎器 bead pressing device



F8-01 F8-02

锥形滚轮 roll and wheel of cones



F8-03 F8-04

六方杆垫
pad of hexagonal stem



F8-05

气压表盒
barometer box



F8-06

支撑座 support seats



F8-07

手控盒 manual control box



F8-08



F8-09

充气枪 air gun



F8-10

机械手压胎器 manipulator pressing device



F8-11

大车扒胎工具套装 grilled tire tools suit of cart



F8-12

二位2、3、4通气动把手
pneumatic handle



F8-13 F8-14

撬杠 lever



F8-15

撬杠护套
protection cover of crow bar



F8-16

F8-17

电容 capacitance



F9-01

转角盘 angle plate



F9-02

辅助臂滑块 helper slider



F9-03

锁紧气缸总成 the lock cylinder assembly



F9-04

快速螺母 quick lock nut



F10-01

F10-02

F10-03

平衡机皮带 belt of balancer



F10-04

爆冲头 burst demounting heads



F9-05

定心锥护套 protection of centering cone



F9-06

十字开关 cross-switch



F9-07

气控阀 pneumatic control valve



F9-08

反定位皮碗、弹簧 reverse orientation rubber cup



F10-05



F10-06



F10-07

卡钳 caliper



F10-08

F10-09

大扒轮子 tyre changer wheel



F9-09

F9-10

举升机油封 seals of hydraulic lift



F9-11

举升机缆轮 cable pulley of hydraulic lift



F9-12

四轮定位片 orientation sheet



F9-13

平衡轴总成 balancer shaft assembly



F10-10

F10-11

F10-12

F10-13



F10-14

超大锥体 large cone



F10-15

F10-16

镭射盒 laser box



F9-14



F9-15

电机 motor



F9-16

回转连接器 rotary connector



F9-17

大平衡机锥体 vertebral of big balancer



F10-17



F10-18



F10-19



F10-20



F10-21

平衡机夹具 clamping tool of balancer



F11-01



F11-02



F11-03



F11-04

卡尺 callipers



F11-05



F11-06



F11-07

平衡机把手 handle of balancer



F11-08

拉尺总成杆 assembly stem of stretching apparatus



F11-09

拉尺头 head of stretching apparatus



F11-10

大平衡机拉尺杆 stretching apparatus stem of big equilibrator



F11-11

铅块铲 Lead shovel



F11-12



F11-13

压力传感器 pressure sensor



F11-14

刹车电阻 resistor of brake



F11-15

平衡机电源开关 power switch of equilibrator



F11-16

举升机脚垫 pad of hydraulic lift



F11-17



F11-18



F11-19

电脑板 pc board



F12-01



F12-02



F12-03



F12-04

电源板 power board



F12-05



F12-06

光电板 photoelectric board



F12-07



F12-08

各种面板 all kinds of panels



F12-09



F12-10



F12-11



F12-12



F12-13



F12-14



F12-15



F12-16